



EC450SXII/SXIII

◆外形図 General view


図面はEC-SXIII-i17, i26の場合を示す
For EC-SXIII-i17, i26 model (for EC-SXII, visor type will be changed.)




◆取出機取付部 Take-out robot mounting surface



◆基礎図 Foundation



◆金型取付関係図 Mold mounting space



射出ユニット Injection Unit	A	B	C	D	E	F	G	H	I
17A,Y	7452	3617	1936	165	2109	2189	692	1286	-254
17B,BH	7657	3822	2141						
26A	7807	3972	2135						
26B	8007	4172	2335						
36A	8322	4487	2340						
36B	8522	4687	2540						

異常警告表示灯 (オプション) Alarm light tower (Option)	J	K
段数 Number of stages		
1	378	2578
2	419	2619
3	460	2660